Lag time in water quality response to land treatment









Donald W. Meals Steven A. Dressing











Some watershed land treatment projects have reported little or no improvement in water quality after extensive implementation of best management practices (BMPs) in the watershed:

- insufficient landowner participation
- uncooperative weather
- improper selection of BMPs
- mistakes in understanding of pollution sources
- poor experimental design
- inadequate level of treatment


Lag time

An inherent characteristic of natural systems generally defined as the amount of time between an action and the response to that action

Lag time is the time elapsed between installation or adoption of land treatment and measurable improvement of water quality.

If lag time > monitoring period.....

May not show definitive water quality results



Planning & Implementation

- identify pollution sources and critical areas
- engage landowner participation
- design and install management measures
- integrate new practices into cropping and land management cycles.

Stakeholders – especially the general public – will experience the planning and implementation process as part of the wait for results.





BMP Development



BMP Development





• [TP] -15%

• [TKN] -12%

• [TSS] -34%

• E. coli -29%


BMP Development



BMP Development









Source Behavior










Source Behavior








Delivery route

- Direct or adjacent
- Overland flow
- Ground water








Path distance



Path travel rate

- Fast (ditches, tile outlets)
- Moderate
 (overland./subsurface flow in porous soils
- Slow (groundwater infiltration w/o macropores)
- Very slow (regional aquifer)





Precipitation patterns





Nature of pollutant

Dissolved



Nature of pollutant

Particulate




Nature of indicator/impairment

Indicator bacteria

- Die-off from environmental stresses
- Even with survival in aquatic sediments, stock eventually depleted

Synthetic organics

- Persistence
- Bioaccumulation





Nature of indicator/impairment

Habitat





Nature of indicator/impairment

Habitat





Biota






Receiving water response

Bacteria from animal waste





Receiving water response

Transparency? Algae blooms?





P in aquatic sediments



Measurement Components

Design of the monitoring program is a major determinant of ability to discern a response against the background of the variability of natural systems

Sampling frequency


Taking fewer samples a year introduces an additional "statistical" lag time before a change can be effectively documented.

Minimum detectable change = how much change must occur (e.g., from implementation of conservation practices) for the change to be statistically significant.


The minimum detectable change (MDC) is given by

$$MDC = T_{(n_{pre} + n_{post} - k - 2)} \sqrt{\frac{MSE_{pre}}{n_{pre}}} + \frac{MSE_{post}}{n_{post}}$$
(1a)

Richards and Grabow, 2003. Detecting Reductions in Sediment Loads Associated With Ohio's Conservation Reserve Enhancement Program. J. American Water Resour. Assoc. 39(5):1261-1268.







PA – 8 to 12 years to grow riparian forest buffer




Inland Bays, Delaware

Nitrate from poultry operations delivered by ground water

Ground water time of travel from agricultural land to Bays → 50 to 100 yrs

Nutrient management, Vermont



N load to Chesapeake Bay

Nutrient source	Load reductions
Point sources	~immediate
NPS (dissolved)	median time of 10 years
NPS (sediments)	> decades




Estimated that following complete elimination of N applications in the watershed, a 50% reduction in base flow $[NO_3]$ would take ~5 years, with equilibrium reached in about 2040.

Recognize lag time and adjust expectations



Characterize the watershed




Consider lag time in selection of BMPs






Consider lag time in siting of BMPs



Treat sources likely to exhibit short lag times first to increase the probability of demonstrating WQ improvement as quickly as possible. **BUT** → "Quick-fix" practices with minimum lag time should not automatically replace practices implemented in locations that can ultimately yield permanent reductions

Monitor small watersheds close to sources








Select indicators carefully






Design monitoring programs to detect change effectively



Use social indicators as intermediate check on progress →

Are things moving in the right direction?



QUESTIONS?